

TauRIS Nominating Procedures

Prior to setting your clock for shipping of the birds you are able to nominate your birds. Essentially creating more than 1 race within a race.

On your Clock

1. Attach sensor cable to clock.
2. Attach power supply to clock
3. Press Start
4. Press 6 NOMINATION
5. Press 1 WINSPEED
6. This will bring up the Main Nominating Screen
7. Press #
8. Select the bird (first line on your clock display)
9. Press # to select the bird
10. Press # to place an "X" or a "0" in the column of your choice. This will advance you to the next column.
11. Press 0 to advance to the column of your choice
12. Press # when you are finished to accept your nomination choice
13. Repeat steps 8 thru 12 until you are completed with nominating

Your clock is now ready for entering your race data. The nominating information will be transferred to the WinSpeed entry sheet so that you will have a record of how you nominated your birds. When the race is knocked off the race result printout will show every flier's nominated birds in the order that they clocked.